

Designed by: **Sara Oehler**Skill Level: **Beginner** 

## **Materials:**

Soft Flex® Wire, .019 Diameter, Color - 10 inches Sterling Silver Earwires - 1 pair 2mm x 2mm Sterling Silver Crimp Tubes - 8 3mm Fire Polished Beads - 6 beads 6mm Fire Polished Beads - 2 beads

## Tools:

Crimping Pliers
Soft Flex® Professional Flush Cutters

## Instructions:

- 1. Choose your color of Soft Flex® Wire and fire polished beads. Use those creative juices to pair colors together that will make your earrings uniquely yours!
- **2.** Use Soft Flex® Professional Flush Cutters to cut two 3 inch pieces of wire and two 2 inch pieces of wire.
- **3.** Use 1 crimp tube and the crimping pliers to attach 2 inches of wire to one ring of one ear wire.
- 4. String one 3mm fire polished bead.
- **5.** Use 1 crimp tube and the crimping pliers to attach the other end of the wire to the other ring of the ear wire.
- **6.** Use 1 crimp tube and the crimping pliers to attach 3 inches of wire to one ring of the ear wire. String one 3mm fire polished bead, one 6mm fire polished bead, and one 3mm fire polished bead.
- **7.** Use 1 crimp tube and the crimping pliers to attach the other end of the wire to the other ring of the ear wire.
- 8. Repeat Steps 2-7 to make a second earring.





